


PRODUCT SPECIFICATION

ET-ST-ROUGH-01

Foam-Pad Vacuum Lifter for Rough Surfaces

ET-ST-ROUGH-01 is an Easytech foam-pad vacuum lifter for rough surfaces. The listed foam-pad configuration is rated for 300 kg. This does not establish the same performance on every rough or porous material: assess the actual surface, leakage, pad contact and handling orientation with representative workpieces.



Series reference image.

Drive: Configuration-specific

Mounting: Crane hook

Materials: Rough-surface panels

Configuration, complete technical data and selection guidance

Read the specified load and movement with their conditions. This document supports purchasing and project definition; the supplied equipment instructions govern operation and maintenance.

Jenny Zhan | Phone / WhatsApp: +86 135-3727-1735

Technical specifications

Parameter	Specification
Vacuum source	Vacuum generator; no vacuum pump
Vacuum pads	Foam vacuum pad
Air source	Air compressor
Alarm	No alarm fitted to this configuration
Tilting	Pneumatic 90°
Rated load	300 kg

Foam contact and pneumatic vacuum generation

The listed foam-pad configuration is rated for 300 kg. This does not establish the same performance on every rough or porous material: assess the actual surface, leakage, pad contact and handling orientation with representative workpieces.

Compare the published configuration

Selection point	ET-ST-ROUGH-01 - Foam-Pad Vacuum Lifter for Rough Surfaces	ET-ST-ROUGH-02 - Foam-Pad Vacuum Lifter for Rough Surfaces	ET-ST-ROUGH-03 - Foam-Pad Vacuum Lifter for Rough Surfaces
Tilting	Pneumatic 90°	Pneumatic 90°	None
Alarm	No alarm fitted to this configuration	Module alarm included	No alarm fitted to this configuration
Vacuum source	Vacuum generator; no vacuum pump	Vacuum generator; no vacuum pump	Vacuum generator; no vacuum pump
Air source	Air compressor	Air compressor	Air compressor
Rated load	300 kg	300 kg	500 kg

Equipment and intended application

Stone and paving products range from suspended pad frames to rough-surface foam heads and a powered paving manipulator. Selection depends on stone mass, rigidity, surface leakage and the required placement method. The exact product configuration below determines whether it lifts horizontally, tilts or positions a paving element.

Application and integration requirements

Topic	Details
Surface and porosity	Polished stone, textured stone and porous blocks behave differently under vacuum. Test the actual surface, including dust, moisture and any coating, rather than relying on material name.
Slab integrity	Check thickness, unsupported span, cracks and cut-outs. A grip that holds securely can still damage a weak slab if support positions are unsuitable.
Placement task	Record the pickup height, destination height, required tilt and access width. For the paving manipulator, keep the end-effector rating separate from pallet-fork mode.

Installation, inspection and service checks

Topic	Details
Before a lift	Check the seal or foam condition, contact cleanliness, pad coverage and the integrity of the stone.
During handling	Maintain the approved orientation and keep the load clear of personnel and obstacles; do not pull a slab free by side-loading a pad.
Service focus	Dust loading, seal wear and leaks require attention. Isolate the equipment before opening filters or replacing seals.

Troubleshooting priorities

Topic	Details
Unexpected grip, motion or control behaviour	Stop with the workpiece supported. Inspect the affected connection, contact area and power or air supply, then follow the installed equipment instructions before returning to service.
Replacement does not fit or changes performance	Check the component identity and system configuration. Do not modify interfaces or bypass protective functions to make a substitute fit.

Frequently asked questions

What load applies to ET-ST-ROUGH-01?

The listed foam-pad configuration is rated for 300 kg. This does not establish the same performance on every rough or porous material: assess the actual surface, leakage, pad contact and handling orientation with representative workpieces.

What determines compatibility?

Polished stone, textured stone and porous blocks behave differently under vacuum. Test the actual surface, including dust, moisture and any coating, rather than relying on material name.

What needs checking beyond the listed size or load?

Check thickness, unsupported span, cracks and cut-outs. A grip that holds securely can still damage a weak slab if support positions are unsuitable.

What defines the supplied configuration?

The specified model, listed technical arrangement and accepted options define the product. Project drawings, utilities, accessories and installation interfaces must describe the same configuration.

Information for application assessment

- Identify the workpiece material, dimensions, mass, contact surface and centre of gravity. Include the least favourable item in a mixed production range.
- Describe pickup and placement positions, required orientation changes, handling frequency and the site layout.
- Identify the available power or air supply and any host machine, crane, support structure or interface that must be retained.
- State the destination market and required documentation, accessories and packing constraints so the proposed configuration can be assessed as a complete system.

Document scope

This product specification supports equipment selection and project definition. It includes the model data and application guidance presented on the product page. The operating instructions supplied for the actual machine govern commissioning, testing, maintenance procedures and safe use; this specification does not replace them.

[View this model on the Easytech website](#)

Contact Easytech

Dongguan Easytech Automation Mechanical and Electrical Equipment Co., Ltd.

Room 403, No. 212, Zhongxing Road, Dalingshan, Dalingshan Town, Dongguan City

Jenny Zhan | Phone / WhatsApp: +86 135-3727-1735

Email: jennyzhan@auto-easy.com | WeChat: easytech1

<https://www.auto-easy.com/>