

PRODUCT SPECIFICATION

ETJSB-G800F

Electric Tilting & Rotating Glass Lifter

ETJSB-G800F is an Easytech electric tilting & rotating glass lifter. Rated load: 800 kg; Pad diameter: 300 mm; Number of pads: 8 pcs; Equipment dimensions: 1973 × 1100 × 1038 mm; Tilting: Electric 90°.



Main view. Series reference image.

Drive: Battery

Mounting: Crane hook

Materials: Glass

Configuration, complete technical data and selection guidance

Read the specified load and movement with their conditions. This document supports purchasing and project definition; the supplied equipment instructions govern operation and maintenance.

Jenny Zhan | Phone / WhatsApp: +86 135-3727-1735

Technical specifications

Parameter	Specification
Rated load	800 kg
Pad diameter	300 mm
Number of pads	8 pcs
Equipment dimensions	1973 × 1100 × 1038 mm
Tilting	Electric 90°
Rotation	Electric 360°
Battery	12 V
Vacuum circuits	Dual circuits
Net equipment weight	139 kg
Packing dimensions	1230 × 1040 × 380 mm
Gross packed weight	161 kg
Standard operating power supply	Storage battery; no external mains connection during operation
Optional operating power supply	Battery-free external-power version available as a custom configuration; electrical supply determined per order
Total vacuum pump power of dual-system configuration	160 W
Total power of dual-system configuration	1060 W

Powered glass tilt and rotation

These G-F configurations provide electric 90° tilt and electric 360° rotation with dual vacuum circuits. Standard operation uses the battery; an external-power battery-free version is a separately specified custom configuration.

Compare the published configuration

Selection point	ETJSB-G800F - Electric Tilting & Rotating Glass Lifter	ETJSB-G1000F - Electric Tilting & Rotating Glass Lifter	ETJSB-G600F - Electric Tilting & Rotating Glass Lifter
Rated load	800 kg	1000 kg	600 kg
Number of pads	8 pcs	10 pcs	6 pcs
Equipment dimensions	1973 × 1100 × 1038 mm	1973 × 1100 × 1038 mm	1800 × 850 × 1038 mm
Net equipment weight	139 kg	151 kg	127 kg
Vacuum circuits	Dual circuits	Dual circuits	Dual circuits

Equipment and intended application

Vacuum seals the suction pads against the glass; the lifting frame transfers the load to the suspension point. The crane or other supporting machine provides the lift. Tilting changes the glass between horizontal and vertical, while rotation turns it within its plane. The listed drive method applies separately to each movement.

Workpiece suitability and limits

Topic	Details
Contact surface	Use an intact, clean sealing area large enough for every active pad. Holes, frit, textured surfaces, films and protective coatings can change leakage or friction and need an actual-surface test.
Glass geometry	Check panel weight, length, width, thickness, centre of gravity and unsupported overhang. The frame must support the glass without excessive bending; pad diameter alone does not determine the maximum panel size.
Curved or asymmetric glass	Use the configuration specifically intended for the curvature and contact positions. A flat-glass load rating must not be transferred to a curved-pad option or an off-centre arrangement.

Configuration and supply boundaries

Topic	Details
Vacuum and pad arrangement	The pad count, pad size, circuit description and power supply in the table define the listed version. A dual-circuit description is not evidence of a particular certification or of unrestricted continued lifting after a fault.
Movement and control	Manual, pneumatic, electric and hydraulic movements require different operator actions and utilities. Distinguish vacuum grip/release control from tilt and rotation control.
Suspension and support	The lifter is a below-the-hook attachment unless a different mounting is stated. The supporting crane must carry the workpiece, lifter and all associated lifting accessories.
Options	Only the alternatives explicitly listed for this product are specified options. Additional arms, curved pads, remote controls or a different power package require a defined configuration and corresponding load assessment.

Installation and commissioning

- Check the crane hook, suspension connection and retention latch. Confirm the total suspended mass and clearances through the entire lift and turning path.
- Set the pad spread around the panel centre of gravity. Lock all adjustable members and route hoses so they cannot kink, rub or become trapped during tilting and rotation.
- For a battery version, check charge state, battery connections and charger input. For a mains or compressed-air version, use the stated utility requirements; a charging voltage is not an operating supply.
- Before production, perform the prescribed vacuum, warning-device and functional checks with the installed arrangement. Changing pad positions or removing pads requires a capacity and balance review.

Handling sequence

1. Inspect pads, frame, suspension, hoses and available power. Check the panel and plan a supported set-down location.
2. Place all active pads fully on the intended contact areas. Apply vacuum and check the indication for every fitted circuit before lifting.
3. Make a controlled initial lift and check balance. Keep people clear of the load path and use only the listed tilt/rotation functions within the approved load configuration.
4. Set the glass onto a suitable support, ensure the weight has transferred to it, then release vacuum. Do not use the release control while the panel is suspended.

Inspection, maintenance and replacement parts

Topic	Details
Pads and seals	Keep contact faces clean using a material-compatible method. Replace damaged, hardened or worn seals; check for marks or chemical effects on coated glass.
Vacuum circuit	Inspect hoses, connectors, filters and gauges. Check fitted warning and non-return devices according to the operating instructions; never assume an indefinite hold time after power loss.
Moving frame	Check pad mounts, locking pins, extension arms and tilt/rotation mechanisms. Isolate power and support moving parts before repair.
Battery and storage	Inspect the battery and charging leads, maintain charge according to the battery instructions and store the pad faces clear of damaging surfaces.

Troubleshooting priorities

Topic	Details
Vacuum does not reach the operating range	Keep the glass supported. Check sealing area, contamination, pad condition, closed valves, hose leaks and power supply before a further lift.
Vacuum falls or a warning operates during lifting	Set the load down by the prescribed safe procedure and stop use. Find the leak or power fault; do not silence the warning and continue lifting.
Glass tilts unexpectedly or a lock will not engage	Support the panel, stop movement and check balance, pad layout and the locking/drive mechanism. Do not force a loaded mechanism past its travel limit.

Frequently asked questions

What load should I use when selecting ETJSB-G800F?

The stated rated load for ETJSB-G800F is 800 kg. Apply it only to the specified configuration and operating conditions. Include the workpiece geometry, orientation and any tooling in the application assessment; do not combine separate maximum reach, height and capacity values.

Can I remove pads to handle smaller glass?

Only with an approved layout and revised capacity. A disconnected pad contributes no holding force; balance, glass overhang and the active circuit arrangement must also remain suitable.

Does the charger voltage power the lift?

On battery equipment the battery powers the on-board functions and the charger has its own AC input. A mains-powered variant is a different configuration, not an automatic operating mode of the battery unit.

Is a load rating sufficient to select the lifter?

No. The pad contact area, glass size and thickness, orientation, centre of gravity and supporting crane all have to fit the task. The technical table and configuration notes should be read together.

Information for application assessment

- Identify the workpiece material, dimensions, mass, contact surface and centre of gravity. Include the least favourable item in a mixed production range.
- Describe pickup and placement positions, required orientation changes, handling frequency and the site layout.
- Identify the available power or air supply and any host machine, crane, support structure or interface that must be retained.
- State the destination market and required documentation, accessories and packing constraints so the proposed configuration can be assessed as a complete system.

Document scope

This product specification supports equipment selection and project definition. It includes the model data and application guidance presented on the product page. The operating instructions supplied for the actual machine govern commissioning, testing, maintenance procedures and safe use; this specification does not replace them.

Product views and application references



Rear structure. Series reference image.



Horizontal gripping position. Series reference image.



Series reference image.



Series reference image.



Series reference image.



Series reference image.



Side structure. Series reference image.



Series reference image.



Resting position. Series reference image.



Series reference image.



Series reference image.

Contact Easytech

Dongguan Easytech Automation Mechanical and Electrical Equipment Co., Ltd.

Room 403, No. 212, Zhongxing Road, Dalingshan, Dalingshan Town, Dongguan City

Jenny Zhan | Phone / WhatsApp: +86 135-3727-1735

Email: jennyzhan@auto-easy.com | WeChat: easytech1

<https://www.auto-easy.com/>