

## PRODUCT SPECIFICATION

# ETJSB-Q300-B4M

## Pneumatic Jib Crane Vacuum Lifting System

ETJSB-Q300-B4M is an Easytech pneumatic jib crane vacuum lifting system. System rated load: 300 kg; Column dimensions: 3320 mm; Lifting stroke: 100-1100 mm; Maximum workpiece dimensions: 3000 × 1500 mm; Air supply pressure: 0.6-0.8 MPa.



Series reference image.

## Configuration, complete technical data and selection guidance

Read the specified load and movement with their conditions. This document supports purchasing and project definition; the supplied equipment instructions govern operation and maintenance.

Jenny Zhan | Phone / WhatsApp: +86 135-3727-1735

## Configuration at a glance

|           |                      |
|-----------|----------------------|
| Drive     | Compressed air       |
| Mounting  | Floor-mounted column |
| Materials | Metal sheets         |

## Technical specifications

| Parameter                    | Specification         |
|------------------------------|-----------------------|
| System rated load            | 300 kg                |
| Column dimensions            | 3320 mm               |
| Jib length                   | 4000 mm               |
| Lifting stroke               | 100-1100 mm           |
| Maximum workpiece dimensions | 3000 × 1500 mm        |
| Air supply pressure          | 0.6-0.8 MPa           |
| Equipment dimensions         | 3430 × 4000 × 2000 mm |
| Number of pads               | 8 pcs                 |
| Pad diameter                 | 200 mm                |

## Pneumatic vacuum workstation coverage

The system uses 0.6-0.8 MPa compressed-air supply and lists a 100-1,100 mm lifting stroke. Compare the chosen 3 m or 4 m jib against the workstation and the specific system load; air-supply pressure is not a vacuum level.

## Compare the published configuration

| Selection point              | ETJSB-Q300-B4M -<br>Pneumatic Jib Crane<br>Vacuum Lifting System | ETJSB-Q500-B3M -<br>Pneumatic Jib Crane<br>Vacuum Lifting System | ETJSB-Q300-B3M -<br>Pneumatic Jib Crane<br>Vacuum Lifting System |
|------------------------------|------------------------------------------------------------------|------------------------------------------------------------------|------------------------------------------------------------------|
| System rated load            | 300 kg                                                           | 500 kg                                                           | 300 kg                                                           |
| Jib length                   | 4000 mm                                                          | 3000 mm                                                          | 3000 mm                                                          |
| Lifting stroke               | 100-1100 mm                                                      | 100-1100 mm                                                      | 100-1100 mm                                                      |
| Maximum workpiece dimensions | 3000 × 1500 mm                                                   | 3000 × 1500 mm                                                   | 3000 × 1500 mm                                                   |
| Air supply pressure          | 0.6-0.8 MPa                                                      | 0.6-0.8 MPa                                                      | 0.6-0.8 MPa                                                      |

## Equipment and intended application

The crane or workstation structure supports the lifting device and its load over the intended working area. A column-and-arm structure, a complete vacuum-jib system and a cylinder/pad assembly are different supply scopes. The scope specified below determines what must be added to form a working system.

## Application and integration requirements

| Topic                 | Details                                                                                                                                                               |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Coverage              | Plot the pickup and placement positions, arm sweep or rail travel and obstructions. Arm length is not the same as unobstructed usable reach.                          |
| Headroom              | Allow for the structure, trolley, hoist or cylinder, attachment and workpiece. Check the highest placement and lowest pickup against the complete installed assembly. |
| Foundation or support | Assess the column foundation, wall or overhead structure for the full system loads. Do not infer an anchor size or foundation depth from rated capacity alone.        |

## Installation, inspection and service checks

| Topic         | Details                                                                                                                                                           |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Installation  | Use the approved structural arrangement and foundation/anchor design. Check alignment, fixings, travel stops and routing of utilities.                            |
| Commissioning | Test movement and controls unloaded, verify the lifting attachment and complete the prescribed load checks before production.                                     |
| Maintenance   | Inspect structural connections, trolley or pivot wear, stops and the lifting assembly. Stop operation when loose fixings, distortion or abnormal travel is found. |

## Troubleshooting priorities

| Topic                                           | Details                                                                                                                                                                                 |
|-------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Unexpected grip, motion or control behaviour    | Stop with the workpiece supported. Inspect the affected connection, contact area and power or air supply, then follow the installed equipment instructions before returning to service. |
| Replacement does not fit or changes performance | Check the component identity and system configuration. Do not modify interfaces or bypass protective functions to make a substitute fit.                                                |

## Frequently asked questions

### What load should I use when selecting ETJSB-Q300-B4M?

The stated rated load for ETJSB-Q300-B4M is 300 kg. Apply it only to the specified configuration and operating conditions. Include the workpiece geometry, orientation and any tooling in the application assessment; do not combine separate maximum reach, height and capacity values.

### What determines compatibility?

Plot the pickup and placement positions, arm sweep or rail travel and obstructions. Arm length is not the same as unobstructed usable reach.

### What needs checking beyond the listed size or load?

Allow for the structure, trolley, hoist or cylinder, attachment and workpiece. Check the highest placement and lowest pickup against the complete installed assembly.

### What defines the supplied configuration?

The specified model, listed technical arrangement and accepted options define the product. Project drawings, utilities, accessories and installation interfaces must describe the same configuration.

## Information for application assessment

- Identify the workpiece material, dimensions, mass, contact surface and centre of gravity. Include the least favourable item in a mixed production range.

- Describe pickup and placement positions, required orientation changes, handling frequency and the site layout.
- Identify the available power or air supply and any host machine, crane, support structure or interface that must be retained.
- State the destination market and required documentation, accessories and packing constraints so the proposed configuration can be assessed as a complete system.

## Document scope

This product specification supports equipment selection and project definition. It includes the model data and application guidance presented on the product page. The operating instructions supplied for the actual machine govern commissioning, testing, maintenance procedures and safe use; this specification does not replace them.

## Contact Easytech

Dongguan Easytech Automation Mechanical and Electrical Equipment Co., Ltd.

Room 403, No. 212, Zhongxing Road, Dalingshan, Dalingshan Town, Dongguan City

Jenny Zhan | Phone / WhatsApp: +86 135-3727-1735

Email: [jennyzhan@auto-easy.com](mailto:jennyzhan@auto-easy.com) | WeChat: easytech1

<https://www.auto-easy.com/>